

Easitune



FITTING WELDIN

For Example

Weld on top. Bronze weld only !!

Drill hole after welding, in three stages 3 mm, 7 mm, 11 mm.

Centre punch before drilling first hole.

The 3 stages lets you adjust the central position of the hole if your initial hole is slightly off centre.

All muffler measurements are to centre of weldin

MINIROK – 100 mm from motor end of muffler

KA – 115 mm from motor end of muffler

X30 – 120mm from motor end of muffler